
Muundo

Inspired by nature



Terra Dining Table Split Top Assembly Guide



! DO NOT MOVE OR LIFT THE TABLE BY THE GLASS/CERAMIC TOP !


To move the table safely, first remove the glass/ceramic top modules from the metal frame.

Lift and move the table by holding the metal frame only.
Place the table in the desired location, then reinstall the glass/ceramic top modules.


After reinstalling the tabletop, make sure all screws on the locking systems are securely tightened to prevent any movement of the glass/ceramic modules.

Parts List:

M6 HEX SCREW X13




TOP METAL FRAME X1




CORNER PROTECTORS/SPACERS X2



LEG + MOUNTING PLATE X1




M6 HEX KEY X1




Glass/Ceramic QTY



20x110cm:
-x1 for 180x110 top
-x3 for 220x110 top
-x2 for 240x110 top
-x4 for 280x110 top
-x3 for 300x110 top



40x110cm:
-x2 for 180x110 top
-x2 for 220x110 top
-x3 for 240x110 top
-x3 for 280x110 top
-x4 for 300x110 top




End piece:
-x2 for all top sizes

STEP 1

Unpack the two cardboard boxes containing
the leg and the top metal frame.


STEP 2

Align the top metal frame with the metal mounting plate.



STEP 3


Using the provided screws and hex key,
securely fasten the leg to the top metal frame.




STEP 4

With the main table structure now assembled, check the top configuratoin carefuly lift the coresponding central glass/ceramic panel with two people. Each person should hold one end of the panel to ensure safe handling.

Place the panel onto the central of the metal frame, making sure the frame sits correctly betweenthe two plastic locking supports located underneath the glass.







*For a correct installation use the guidlines that can be found on the metal frame for centring the central glass/ceramic panel.

STEP 5

Once the glass is properly aligned with the metal frame,
rotate the locking system toward the frame to secure the glass top firmly in place.





Locked position


If the locking system is difficult to rotate, slightly loosen the screw on the locking mechanism.Once the mechanism is in the correct locking position, retighten the screw.

! Do not force the locking system if you feel excessive resistance,
as this may damage the mechanism or the glass top !

STEP 6

Place the corner spacers on the edges of the secured glass panels.
Carefully position the next glass/ceramic top module against the spacers, making sure it sits snugly and is correctly aligned. Rotate the locking system to secure the new glass/ceramic module to the frame. Once the module is securely fixed, remove the spacers and place them on the outer corners of the newly installed module.


Repeat this process until all glass/ceramic top modules are securely fixed to the metal frame.




*Refer to the next page to see the order in which the modules should be installed.

The arrangement varies depending on the tabletop dimensions.


300x110




280x110



240x110



220x110



180x110



! DO NOT MOVE OR LIFT THE TABLE BY THE GLASS/CERAMIC TOP !

To move the table safely, first remove the glass/ceramic top modules from the metal frame.

Lift and move the table by holding the metal frame only.
Place the table in the desired location, then reinstall the glass/ceramic top modules.

After reinstalling the tabletop, make sure all screws on the locking systems are securely tightened to prevent any movement of the glass/ceramic modules.

Maintenance

DISCLAIMER

Care and Maintenance of Your Glass/Ceramic Table:

Your table is designed with a glass/ceramic tabletop and a durable metal frame. To maintain its appearance and ensure long-lasting use, please follow the care and maintenance guidelines below.

Due to the nature of glass and ceramic materials, minor variations in colour, texture, pattern, or finish may occur. These variations are normal and contribute to the individual appearance of each tabletop.

Staining Risk:

Although the glass/ceramic tabletop is designed for everyday use, it should be handled with care.
Avoid dropping heavy or sharp objects onto the surface, particularly near the edges and corners, as impacts may cause chips, cracks, or other damage.
Do not sit, stand, or place excessive weight on the tabletop.

Cleaning Instructions:

Clean the tabletop using a soft cloth, water, and a mild cleaning product suitable for glass or ceramic surfaces.
Do not use abrasive sponges, scouring pads, or aggressive cleaning products, as these may damage or scratch the surface.

Hot Objects and Tableware:

We recommend using coasters, placemats, or trivets underneath hot cookware, drinks, and decorative objects To protect the tabletop and minimise the risk of scratches or thermal damage. Avoid dragging heavy, rough, or sharp objects across the surface.

Warranty Void:

Failure to follow these guidelines will void the warranty on the table.

If you have further questions, don't hesitate to contact us.

E-mail/ Info@muundo.be
Instagram/ Muundo.be